

Partner for
disinfection



pharma *Rw*

Bacillol[®] 25 (Ready to Use)

Aldehyde-free quick acting, surface disinfectant

For instant disinfection of pharmaceutical equipment and sensitive surfaces. Is an aldehyde free, quick acting, alcoholic, ready-to-use, surface disinfectant with special material tolerance, and corrosion inhibitors.

The effectivity of **Bacillol[®] 25** against Staphylococcus aureus, P. Aeruginosa, E. coli, Candida Albicans, is tested & proven to be > 99.99%



Bacillo[®] 25

Requires 25 seconds to 5 minutes contact. In pharma industries, **Bacillo[®] 25** is useful for cleaning & disinfection of monitors, pharma equipments, trolleys, tables, electronic equipments. Just spray & wipe for excellent results.

Composition :

Each 100g contains :

- Ethanol : 10g
- 2-Propanol : 9g
- 1-Propanol : 6g
- Corrosion Inhibitors

Product Qualities :

- Complete Microbicidal including bacteria (also Salmonella), fungi (also Skin-moulds), viruses, including HIV and Rota.
- Particularly material caring : does not cause any fissure, rupture or cracks.
- Inconformity with different plastics including Makrolon, Acrylglass, Plexiglass.
- Free of formaldehyde.
- Excellent moistening.
- Dries without visible residue.
- Does not harm skin.

Use in Pharma Industries :

- For rapid cleaning and disinfection of sensitive surfaces.
- Used in areas where quick reaction period is necessary i.e. for reduction of idle periods in production plants.
- For cleaning & disinfection of "difficult-to-approach" surfaces e.g. threads, stopcorks, valves etc.
- For cleaning & disinfection of protective covers of filling and packing machines, palettes, cupboards, table working surfaces etc.
- For cleaning & disinfection of TV Screens, Monitors, cables, cords, adaptors, connectors, wires, trolleys etc.

Application and Dosaging :

- **Bacillo[®] 25** is ready to use in 250ml cylindrical bottles.
- Specially developed spray-head is provided with each bottle.
- Two nozzle options : Jet spray and Mist Spray.

Method of use :

- Spray liberally on desired surface, with appropriate nozzle.
- Allow 25 seconds to 5 minutes contact, for optimum results.
- Wipe with clean cellulose cloth.

Precautions :

- No disinfection to be done when combustible vapours (ether etc.) are present in the room.
- Hot surfaces must be cooled sufficiently before using **Bacillo[®] 25**.
- No "switching" actions if electronic devices are in use, while disinfecting.
- For best results, ventilation should be kept low, or started 5 minutes after spraying.

Presentation :

- 250ml bottle with spray : 20 bottles /1 Carton
- 5 Ltrs. Jar : 2 Jars / Carton.

Please Note :

- Microbicidal reports available on request.
- Registered in 43 countries world wide.
- Validations, COA / batch are available on request.

Shelf Life :

- 3 years.

Some International pharma & food processing Industries currently using Bacillo[®] 25;

- Bergader, Waging
- Edelweiss Kasewerke, Kempten
- Milchunion, Pronsfeld
- Nestle Luneburg
- Nordmilch e. G., Hohenwestsedt
- Schwartauer Werke, Bad Schwartau.
- Conditorei Copenrath & Wiese, Westerkappeln

Our Indian Customers :

- AurobindoPharma
- Aventis Pharma Ltd.
- Biochem
- Chiron Behring Vaccines Ltd.
- Cadila Health Care Ltd.
- Cadila Zydus
- Centaur Pharma Ltd.
- Cipla Ltd.
- Core Parental
- Glenmark
- Indoco Remedies Ltd.
- Merck Ltd.
- Micro Labs Ltd.
- Okasa Ltd.
- Ranbaxy Ltd.
- Ratio Pharma Ltd.
- Shreya Life Sciences
- Sun Pharma
- Themis
- Tulip Diagnostics (P) Ltd.
- Wockhardt

